

While the machine is embroidering it can move as many stitches you need backward just by pressing **STOP**. The machine will back up.

This is the button that changes the speed of the movement when moving forward or backward through a design.




Press this button.

You will see the icon on screen display 2 arrows. When you press **START** or **STOP** this will make the embroidery machine move forward or backward quickly through the design. The hoop will not move but you will be able to see the progress on the display. Press **START** to start the progression forward or **STOP** to start the progression backward. Then press **STOP** to halt the progression.



If you want to move forward quickly but not as fast as described above, press the Embroidery Float button again until the on-screen icon displays one arrow. When you press the **START** button the hoop will move forward through the design just as it does when the **STOP** button is pressed to move backward.



If you want to move forward by color, press the Embroidery Float button again until the on-screen icon displays **ADD**. You will now see 2 new buttons in the lower left corner of the display. The first one will move forward 1 color when pressed, and the second one will move back 1 color when pressed.