



Steps to threading the Pro Capsule



STEP 1 Make sure thread goes between the plates



STEP 2 Make sure to go around loop and half around the wheel



Step 3



Step 4

Step 5

