



If the machine do not pick bobbin or if the thread came out of the needle adjust the lever up or down.